

Experiment: Study of LAN Topology, Network devices and Address Configuration. ①

Objective:→

- ① To Study the LAN topology used in College Campus.
- ② To identify networking device & understand their function.
- ③ To analyze wired & wireless communication method used in the network.
- ④ To measure speed of network for wired & wireless connections.
- ⑤ To obtain MAC, IP Address & Subnet mask.

Problem Statement-1

- Draw & identify LAN topology of College Campus & clearly label all components. Such as router, switches etc.

Solu: The college campus network observed in this study consists of:→

- * Layer-3 Core Switches in the Server Room.
- * Managed by POE + Switches.
- * Wireless Access point (APs)
- * Ethernet port in classroom & Laboratories.

Question no:1

→ Network Topology

Hybrid Hierarchical Topology which combines:

1. Tree Topology
2. Extended Star Topology
3. Ring Topology (Server room)

→ The network hierarchical layers: →

- ① Core layer.
- ② Distribution layer.
- ③ Access layer

① Core layer: → Core layer contains Server Room and server room have firewall, Router, 2-L3+ Switches, Patch Rack, Server, inverter etc.

② Distribution layer: →

* Distribution layer contains 4-Switches

* The 4 switches are: →

- ① Main Build → R7 (Room no-213, 2nd floor).
- ② Main Build → R1 (Room no. → 301, 5th floor).
- ③ Main Build → R6 (Room no-113, 1st floor).
- ④ Main Build → R2 (Room no. 201, 2nd floor).

* This 4-Switches contains: →

① 18 Port Gigabit Easy Smart Switch with 16-Port. TL-SG412 18MPE

② SG3428 XMP → 24 Port Gigabit & 4-port 10GE SFP+, L2+ Managed Switches switch with 24 port PoE+.

③
→ Now let's discuss these 2 above components: →

① TP-link TL-SG1218 MPE

- * Likely used for: CCTV camera, wifi access point, etc.
- * 18 port Gigabit "Easy Smart" Switch.
- * 16 port Support PoE+

② TP-link Omada SG3428X MP

- * Higher-end managed layer 2+ Switch.
- * 24 PoE+ Port, uplinks, 10G SFP for each floor.

→ Access Layer: →

- * Access Layer contains 3-switches i.e. →
 - (I) Main Build R1 - [Room no- 301, 3rd floor].
 - (II) Main Build R4 [Room no- 05, Ground Floor]
 - (III) Main Build R5 [Room no- 18, Ground Floor].


* Every switches act as access Layer which helps to provide network connectivity to all classroom, Lab, Faculty Room, etc.

* Access Layer directly connect: →

- ① Ethernet Port
- ② Wireless AP.
- ③ Lab System.


→ Server Room Architecture / Topology :- →

(4)



TOPOLOGY

(5)




→ R1, R7, R2, R6 → Distribution layer.

→ Server room → Core layer.

→ R1, R2, R3, R4, R5, R6, R7 → Access layer.

ACCESS LAYER SWITCH (3rd Floor 301)

⑥



2. Identify Network Devices :->

- List all networking devices used in the LAN
- Mention the function of each device.

1. Router

Function:->

- Connects the LAN to the Internet or other networks.
- Assigns IP addresses (DHCP).
- Routes data packets between different networks.

2. Switch

Function:->

- Connects multiple devices (PCs, printers, etc) within the LAN.
- Transfers data to the correct device using MAC addresses.

3. Wireless Access Point / Wi-Fi Router

Function:->

- Provides wireless (Wi-Fi) connectivity to devices in the LAN.
- Allows laptops/mobile devices to join the Network.

4. Network Interface Card (NIC) / Network Adapter

Function:->

- Hardware inside a computer that enables network connection.
- Example: Wi-Fi Adapter, VMware Network Adapter.

5. Computer / Host Device

Function:->

- End device used to send, receive, and process data on the LAN.

Question no:2

6. Ethernet Cable.

(if wired LAN is used)

Function :- →

- Physically connects devices like Computers, Switches and routers for data transfer.

7. Modem

(if Internet access is included)

Function :- →

- Connects the router/LAN to the ISP (Internet Services Provider)
- Converts ISP signals into digital network signals


```
Windows PowerShell
PS C:\Users\Alisha> ipconfig

Windows IP Configuration

Wireless LAN adapter Local Area Connection* 9:

    Media State . . . . . : Media disconnected
    Connection-specific DNS Suffix  . :


Wireless LAN adapter Local Area Connection* 10:

    Media State . . . . . : Media disconnected
    Connection-specific DNS Suffix  . :

Wireless LAN adapter Wi-Fi:

    Connection-specific DNS Suffix  . :
    Link-local IPv6 Address . . . . . : fe80::c2b6:bff4:eea1:7d6d%3
    IPv4 Address. . . . . : 10.85.19.61
    Subnet Mask . . . . . : 255.255.248.0
    Default Gateway . . . . . : 10.85.16.1
PS C:\Users\Alisha> |
```

Wireless Connection



Network Speed(104Kbps)


```
Windows PowerShell
Copyright (C) Microsoft Corporation. All rights reserved.

Install the latest PowerShell for new features and improvements! https://aka.ms/PSWindows

PS C:\Users\Alisha> getmac

Physical Address      Transport Name
=====
58-CD-C9-90-1A-E9     \Device\NPF{09E9A9B6-C94C-4E50-9D50-673AC96B3636}
PS C:\Users\Alisha> |
```

MAC Address

IP Address

6. Explain Observations :

• Briefly explain :

→ Difference between wired and wireless speed.

→ Role of Subnet mask in networking.

1. Ans:

Wired Network

- Uses Ethernet Cable for connection.
- Generally faster and more stable.
- Lower latency (Faster response time).
- More secure because physical access is required.

Wireless Network

- Uses Wi-Fi signals for connection.
- Speed may vary due to distance and interference.
- Higher latency compared to wired networks.
- Less secure if Wi-Fi security is weak.

Example: In a computer lab, a PC connected through an Ethernet cable may get 100 Mbps, while a laptop connected through Wi-Fi may get 60-80 Mbps depending on signal strength.

2. Role of Subnet mask in networking : →

Ans: A Subnet Mask is used to identify the network portion and host portion of an IP address. It helps device determine whether another device is on the same network or a different network.

Example: • IP address : 192.168.1.10
• Subnet Mask : 255.255.255.0

Here : → • Network ID = 192.168.1.0
• Host ID = 10

- All devices with addresses 192.168.1.x belong to the same network and can communicate directly

List of Devices and Their Roles : →

<u>Device</u>	<u>Role</u>
1. Router	: Connects local Network to the Internet.
2. Switch	: Connects Multiple devices with a LAN.
3. Computer/Laptop	: Sends and receives data.
4. Access Point/Wifi Router	: Provides wireless connectivity.
5. Modem	: Connects Network to ISP.

Table OF Network Parameters : →

<u>Parameter</u>	<u>Example Value</u>
MAC Address	00:1A:2B:3C:4D:5E
IP Address	192.168.1.10
Default Gateway	192.168.1.1

Network Diagram : →

